

Thermal management for electrical enclosures



FSHT

FAN ASSISTED HEATERS
User's manual

www.alfaelectric.com

WARNING

- Safety of FSHT is warranted only by proper use of these instruction which must be kept.
- Installation must be done by qualified personnel only after power supply disconnecting
- Before any operation, switch off the power supply.
- Install the FSHT only inside an electrical enclosure, in vertical position, in the bottom part of cabinet.
- FSHT series is fitted with dedicated ground terminal, it must be connected with an adequate ground circuit according to the local norms and safety regulations which govern the use of electrical material;
- Upstream of the electrical connection, an efficient disconnection system must be provided
- Protection against access to live parts must be warranty by installer
- Don't install FSHT in ambient with excessive moisture and dirt
- Installation position of FSHT must be selected to ensure good ventilation. Take care that any internal components of enclosure don't obstruct air passage.
- Do not mount FSHT under easily inflammable materials
- Follow all technical data shown in this manual.

This manual contains the information necessary for the product to be installed correctly and also instructions for its maintenance and use; we therefore recommend that the utmost attention is paid to the following instructions.

Though this manual has been issued with the greatest care, ALFA ELECTRIC will not take any responsibility deriving from its use. The same applies to each person or Company involved in the issuing of this manual.

This document is the exclusive property of ALFA ELECTRIC which forbids any reproduction and divulgation, even in part, of the document, unless expressly authorized.

ALFA ELECTRIC reserves the right to make any formal or functional changes at any moment and without any notice.

1 - DESCRIPTION

GENERAL DESCRIPTION

FSHT is an anticondensation fan assisted heaters optimized to avoid condensation or grant a minimum temperature in closed cabinets. It is fitted with screw terminal for electrical connection, A green led shows the status of heater, if it is light the heater is turned on and it works properly.

Tab.1

Model	Heating Capacity* [W]	Power supply [V/Hz]
FSHT250	250	230/50-60
FSHT251	250	115/50-60
FSHT400	400	230/50-60
FSHT401	400	115/50-60
FSHT500	500	230/50-60
FSHT501	500	115/50-60
FSHT750	750	230/50-60
FSHT751	750	115/50-60
FSHT750.080	750	Heater 480/50-60 Fan 230/50-60

2 - INSTALLATION


2.1 GENERAL DESCRIPTION

FSHT are fitted by clip for DIN rail 35mm mounting.

2.2 INSTALLATION

WARNING


- Before any operation, switch off the power supply
- Keep a thermal safety clearance of 300 mm from the air outlet and 100mm from air inlet, 60mm of clearance from sides
- Install vertically (cables below heater) in the bottom part of cabinet.
- Do not mount heaters over easily inflammable materials
- Do not operate in corrosive ambient air.
- Install FSHT only in an electrical enclosure



3 - REMOVAL

- Before any operation, switch off the power supply

WARNING: Heater surface is very hot for 15-20 minutes after electrical disconnection.




4 - ELECTRICAL CONNECTION

4.1 ELECTRICAL CONNECTION

FSHT electrical connection must be done by trained electricians according national electrical safety codes.

- Before any operation, disconnect cabinet

- Connect FSHT according to wiring diagram
- Connect the FSHT to the power supply by adequate section cable according to dimension allowed by terminal.
- FSHT series is fitted with dedicated ground terminal, it must be connected with an adequate ground circuit according to the local norms and safety regulations which govern the use of electrical material;
- Use a thermostat ALFAELECTRIC THR series to pilot heating functions according to enclosure temperature. (not for 480V heaters)
- Connect the cabinet



WARNING: FSHT is fitted with thermal cut out fuse in case of fan failure. It avoids temperature rises over value which could damage the unit.

4.2 ELECTRICAL DISCONNECTION

WARNING

- Disconnection must be done by qualified personnel only after power supply disconnecting
- Before any operation, switch off the power supply.

5 - CLEANING, MAINTENANCE AND DISPOSAL

Cleaning and maintenance must be done only after switching off power supply. For cleaning use only a wiper and compressed air.

FSHT must be disposed of separately from ordinary household wastes