



FDKES 10 Heat Shrink Joint Kit

FDKES 10 - Instructions

1. Remove outer insulation for length L in the table.
2. Insert the outer heat shrink sleeve on one side of the cable.
3. Remove the core insulation for a length that allows for placing the connectors.
4. Insert the internal heat-shrink sleeves on one side of the individual cores.
4. Make connections with the appropriate connector.
5. Place the internal heat-shrink sleeves on the connectors, and then proceed to shrink.
6. Apply the mastic tape on the cable connections.
7. Centre the outer heat shrink sleeve on the junction and shrink starting from the centre, proceeding towards the ends.
8. Use the heater in a continuous movement so as to avoid localised burning.
9. Wait for the joint to cool before energizing cable.

DESCRIPTION	mm ²	L mm
FDKES 10	4 X 1.5 4 X 2.5	150

