



BACK

Change-over switches CKS


NEXT

For printing and/or save in PDF file format click on the PDF icon




	250	400	630	800	1000	1250
3 Poli	ECKS02503000A	ECKS04003000A	ECKS06303000A	ECKS08003000A	ECKS10003000A	ECKS12503000A
4 Poli	ECKS02504002A	ECKS04004002A	ECKS06304002A	ECKS08004002A	ECKS10004002A	ECKS12504002A
6 Poli	ECKS02506000A	ECKS04006000A	ECKS06306000A	ECKS08006000A	ECKS10006000A	ECKS12506000A
8 Poli	ECKS02508002A	ECKS04008002A	ECKS06308002A	ECKS08008002A	ECKS10008002A	ECKS12508002A

CKS 3/4 Poles



CKS 6/8 Poles



	A (3-6p)	A (6-8p)	B	C	D	E	F	G	H	J	I	K	L	M	N	P	Q	R	S(3-4P)	S(6-8P)	T	U	V	W	X	Y	Z		
ECKS 0250													25					77	121	74								4	
ECKS 0400	260	307	218	193	168	142	65	-	39.5	320	112.3	125	30	177	72	96	6.5	78	122	73	107	43	64	94	274	-	5	10	10.5
ECKS 0630													35					79	123	73							6		
ECKS 0800																		86	134	88							8		
ECKS 1000	320	392	292	252	230	208	87		49	435	134	165	40	221	89	112	6.5	88	136	86	107	48	64	94	384	-	10	12	13
ECKS 1250								30										88	136	86						352	10		